

Instructions

Assembly
Installation
Operation

10/2009



Collect Freestanding/Surface Mount Litter Receptacle

HANDLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on cement or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

CAUTION! This litter receptacle is heavy. To avoid injury or damage to the finish, we recommend using a two-wheeled hand truck to move this item.



Product Components: Unit will arrive assembled - freestanding unit is ready to set in place.

To Open: Press latch bottom on the side of the unit and push the top of the plastic bin until it stops in the tilted position. If equipped with lock, make sure it is unlocked then press the latch.

Recommended Procedure for Surface Mounting Collect Litter:

1. Place Collect unit(s) in desired location. We recommend concrete surfaces for surface mounting.
2. Remove both set screws at the base of the unit using an 1/8" drive hex wrench.
3. Remove the cover plate at the bottom of litter to access the anchor holes and adjustable levelers. Adjustable levelers not available on Mini Litter.
4. Using a 3/16" hex wrench, adjust levelers as required so the unit is plumb and as close to the concrete as possible.
5. Mark drill hole locations through anchor holes provided in bottom of unit.
6. Move unit to allow access for drilling holes.
7. Drill holes at marked locations following all installation instructions from anchor manufacturer. Note: We recommend anchor bolts be no larger than 3/8" diameter. Non-corrosive anchoring hardware is also recommended.
8. Although anchoring procedure and hardware is the responsibility of the installer, Landscape Forms suggests the following options:
 - Poured concrete: Use drop-in type wedge anchors made for 3/8" hex head bolts, or use a sleeve type expansion anchor.
9. Move unit back and install anchoring hardware.
10. Reinstall cover plate and secure using provided 1/4" set screws.