

Instructions

Assembly
Installation
Operation

6/2009

Gretchen Litter Receptacle or Ash Urn - Surface Mount

Recommended procedure for mounting to hard surfacing:

1. Place unit in desired position and rotation.
2. Mark hole location through anchor tabs.
3. Move unit to allow access for drilling holes.
4. Drill holes at marked position for appropriate anchors. Note: Anchors must be no larger than 3/8" diameter. Non-corrosive anchoring hardware is recommended.
5. Although anchoring procedure and hardware is the responsibility of the installer, we suggest the following:
 - Poured concrete: 3/8" diameter, stud type expansion anchor, minimum of 2-1/2" long.
 - Pavers: If pavers are installed over poured concrete, use 3/8" diameter, stud type expansion anchor with enough length to go through brick and into concrete.
 - Wood Deck (at least 2" nominal thickness): 3/8" diameter hex head lag bolt, at least 2-1/2" long.
6. If using expansion anchors, install anchor leaving approximately 1/2" thread protruding from surface. Place unit in position, install hex nut with washer and tighten gently to prevent marring finish.
7. If using lag bolts, place unit in position and install lag with washer. Tighten gently to prevent marring finish.

ASSEMBLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on cement or other hard or textured surface - this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.