

Instructions

Assembly
Installation
Operation

9/2009

Palisade Bench

Product Components:

Bench with 4 glides and 2 surface mounting plates

Recommended Procedure for Mounting to Hard-Surfacing:

1. Place unit in desired position and rotation.
2. Mark hole location through anchor tabs.
3. Move unit to allow access for drilling holes.
4. Drill holes at marked position for appropriate anchors. Note: Anchors must be no larger than 3/8" diameter. Non-corrosive anchoring hardware is recommended.
5. Although anchoring procedure and hardware is the responsibility of the installer, we suggest the following:
 - Poured concrete: 3/8" diameter, stud type expansion anchor, minimum of 2-1/2" long.
 - Pavers: If pavers are installed over poured concrete, use 3/8" diameter, stud type expansion anchor with enough length to go through brick and into concrete.
 - Wood Deck (at least 2" nominal thickness): 3/8" diameter hex head lag bolt, at least 2-1/2" long.
6. If using expansion anchors, install anchor leaving approximately 1/2" thread protruding from surface. Place unit in position, install hex nut with washer and tighten gently to prevent marring finish.
7. If using lag bolts, place unit in position and install lag with washer. Tighten gently to prevent marring finish.