

# Instructions

Assembly  
Installation  
Operation

7/2007

## Parc Centre™ Tables

### Product Assembly:

All Parc Centre™ tables are shipped fully assembled, no assembly is required

**WARNING! TO AVOID INJURY TO PERSONS HANDLING TABLES, USE TWO PERSONS TO TEAM LIFT AND CARRY.**

**HANDLE WITH CARE!** Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on cement or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

### Recommended Procedures for Mounting to Hard-Surfacing:

**NOTE:** The anchoring procedure and hardware are the responsibility of the installer, we suggest the following:

#### Freestanding Table Procedure:

1. Place table in desired position.
2. Adjust levelers on glides to level table. All 4 glides must be touching the mounting surface to provide a stable table.

#### Surface Mounting Procedure:

1. Place table in desired position and rotation.
2. Mark hole locations through holes in base.
3. Move unit to allow access for drilling holes.
4. Drill holes at marked position for appropriate anchors. Note: Anchors must be no larger than 3/8" diameter. Non-corrosive anchoring hardware is recommended.
5. Although anchoring procedure and hardware is the responsibility of the installer, Landscape Forms suggests the following:
  - Poured concrete: 3/8" diameter, stud type expansion anchor, minimum of 2-1/2" long.
  - Pavers: If pavers are installed over poured concrete, use 3/8" diameter, stud type expansion anchor with enough length to go through brick and into concrete.
  - Wood deck (at least 2" nominal thickness): 3/8" diameter hex head lag bolt, at least 2-1/2" long.
6. If using expansion anchors, install anchor leaving approximately 1/2" thread protruding from the table base. Place table in position, install hex nut with washer and tighten gently to prevent marring finish.
7. If using lag bolts, place table in position and install lag with washer. Tighten gently to prevent marring finish.