

Instructions

Assembly
Installation
Operation

05/2008

Village Green™ Bench

Introduction

The Village Green bench is shipped fully assembled with freestanding glides that can be removed for surface mounting.

HANDLE WITH CARE! Pangard II® polyester powder coat is a strong, long-lasting finish. Protect this finish from damage during installation. Use touch-up paint to repair any finish abrasions.

Recommended procedure for surface mounting:

Each leg has a 3/8" thick foot that can accept anchors up to 3/8" thread size. Although the anchoring procedure and hardware are the responsibility of the installer, we suggest the following:

1. Select corrosion resistant anchors appropriate for the surface and security level desired. Your hardware store or builders supply may be able to recommend the proper hardware, tools, and safety equipment.
2. Place the bench in the desired position.
3. Mark hole locations.
4. Move the bench to allow access for drilling holes.
5. Install the anchors and bench according to the anchor manufacturer's instructions.
6. Use stainless steel flat washers to shim units mounted on uneven surfaces.