

Instructions

Assembly
Installation
Operation

7/2007

Chase Park® Bench and Litter Receptacle

HANDLE WITH CARE! Pangard II® Polyester Powder coat is a strong, long-lasting finish. Protect this finish from damage during installation. Place unwrapped powder coated parts on packaging foam or other non-abrasive surface. Do not place or slide powder coated parts on concrete or other hard or abrasive surfaces – this will damage the finish causing rust to occur. Use touch-up paint to repair any finish abrasions.

Chase Park Bench

Recommended Procedure for Surface Mounting:

1. Surface mount benches are shipped with stainless steel mounting plates attached. The plates will accommodate anchors 3/8" diameter or less. We recommend positioning surface mounting plates toward the inside to avoid a tripping hazard. The installer is responsible for anchoring hardware suitable for site conditions. Corrosion resistant anchors are recommended.
2. Place the unit in the desired position. Mark hole locations through anchor holes in mounting plates.
3. Move the unit to allow access for drilling holes.
4. Complete the installation according to the anchor manufacturer's instructions.

Recommended Procedure for Embedding:

1. Position the bench so that the frame legs are plumb and the top front surface of the seat is 18" above finished grade. (Frame legs will extend 20" below grade.)
2. Pour embedding material.

Chase Park Litter Receptacle

CAUTION! This litter receptacle is heavy. To avoid injury or damage to the finish, we recommend using a two-wheeled hand truck to move this item.



Recommended Procedure for Surface Mounting:

1. Freestanding/surface mount receptacle bases have two holes that will accommodate anchors 3/8" diameter or less. (The hole at the center is a drain hole.) The installer is responsible for anchoring hardware suitable for site conditions. Corrosion resistant anchors are recommended. The receptacle should be surface mounted with nylon glides in place.
2. Place the unit in the desired position. Open the door to check clearance.
3. Remove the liner and mark anchor locations through the holes in the base.
4. Move the unit to allow access for drilling holes.
5. Complete the installation according to the anchor manufacturer's instructions.