

### Bench options

#### Included components:

- Bench ships fully assembled.

#### Tools Required:

##### For Surface Mount Bench:

- (8) Non-corrosive anchoring hardware (not included), sized for 9/16" dia hole

##### For Wall Mount Bench:

- (8) Non-corrosive anchoring hardware (not included), sized for 3/4" dia hole

#### PROCEDURE FOR INSTALLATION:

1. Prepare proper concrete slab as required.
2. Freestanding bench (Fig. 1.1) ships with glides installed. Bench can be set in place.

##### For SURFACE MOUNT bench:

1. Set bench in place and mark hole locations, see Fig 1.2.
2. Move bench and drill holes according to diameter and depth required by anchoring hardware manufacturer. Clear holes of debris.
3. Set bench over holes and install anchors.

##### For EMBEDDED MOUNT bench:

1. Prepare footing or slab as required by site conditions and frost depth. See Fig. 1.3 and 1.4 for minimum recommendations.
2. Install bench level and at proper seat height. Brace bench until footing has set.

##### For WALL MOUNT bench:

1. Locate bench in position using temporary blocking. Verify bench seat is level. See Fig. 1.5 for seat height.
2. Mark hole locations.
3. Move bench and drill holes according to diameter and depth required by anchoring hardware manufacturer. Clear holes of debris.
4. Install anchors.

Wall thickness and anchoring type are the responsibility of the installer. Minimum 4000 psi concrete wall is recommended.

**ASSEMBLE WITH CARE!** Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4




Fig. 1.5